

7. Okt. 1982

Only fitting hole is out of given range!

- a) Take canopy off.
- b) Dismount canopy gas strut at forward end.
- c) Fit bracket provisionally using existing hole.
- d) Drill new hole of 6.1 mm in diameter (0.24 in, use drill of drill number size C) 12 mm (0.5 in) above square tube of pedal guide.
- e) Mount bracket according to drawing 4BR-48 using large washer, connect gas strut.

Cracks have been found:

- a) Set circular cutout of new bracket onto tube of pedal guide.
- b) Mark hole on bracket.
- c) Drill hole, see above under d)
- d) Mount bracket according to drawing 4BR-48 using large washer.

If both possibilities apply, a new bracket must be used and a new hole drilled into pedal guide.