

Subject: Ground connection between control stick and C.G. release

Effectivity: LS sailplanes, versions and serial numbers:
LS1-f: S/N 272, 424, 426, 464, 465, 466, 467, 473, 478, 479,
481, 482, 483, 484, 485, 486, 487, 488, 489, 490.
LS3, LS3-V1, LS3-a, LS3-17, LS3-ake, LS3-Std all S/N
LS4: S/N 4000, 4001, 4002, 4003, 4004, 4006, 4007, 4008,
4009, 4010, 4012, 4013, 4016, 4018, 4020, 4021, 4022,
4023, 4024, 4025, 4027, 4028, 4037, 4038, 4039, 4040,
4042, 4045, 4047, 4048, 4050, 4068, 4075, 4076, 4077,
4082, 4083, 4085, 4088, 4099.

Accomplishment: Within 6 months

Reason: Ground connection between control stick and C.G. release via
landing gear drive may be interrupted.

Instructions: Installation of ground cable between control stick and C.G.
release according to Instruction 41/3026/4004-2 and drawing
41/3026/4004-3.

Material: See Instruction.

Weight and Balance: Not affected.

Remarks: Material, Instruction and drawing may be obtained from manufacturer
or via agents.
Accomplishment should be entered in logbook and signed by inspector