


Fuselage Water Ballast System

| No. | Denomination | Drawing |
|-----|---------------------------------|----------|
| 1 | Cockpit lever (Integral tank) | 4R12-141 |
| 2 | Tail tank valve (Integral tank) | 1BR-213 |
| 9 | Cockpit lever (Slide-in tank) | 1BR-188a |
| 10 | Water ballast drive distributor | 1BR-188a |
| 11 | Right side bowden cable | 4R12-129 |
| 12 | Right side fuselage lever | 4R12-113 |
| 13 | Left side bowden cable | 4R12-130 |
| 14 | Left side fuselage lever | 4R12-114 |
| 15 | Slide-in tail tank | 3GR-122 |
| 16 | Slide-in tail tank valve | 4BR-121 |



| | | |
|-------------------------------------|--------------------------|-----------|
| Erstellt: 28.02.00 <i>Givcke</i> | Geprüft: <i>Wapka</i> | Complies: |
|-------------------------------------|--------------------------|-----------|